

DCH/37 CHAIR



FRAME: DCH/37
DESCRIPTION: Chair

OVERALL WIDTH: 33"
OVERALL DEPTH: 37"
INSIDE WIDTH: 23"
OVERALL HEIGHT: 32"
SEAT HEIGHT: 18"
SEAT DEPTH: 22"
ARM HEIGHT: 24"

ARM: 10A Square to Front
BACK: 9B T-Border
BASE: 20C Acrylic Ledge
OPTION: Blind Stitch

the choice is yours



13 arms

6 backs

10 bases



1A
 Fan to Front
 OW: 5"



2A
 Fan with T-Cushion
 OW: 5"



3A
 English with T-Cushion
 OW: 5"



4A
 Track to Front
 OW: 3.5"



5A
 Track with T-Cushion
 OW: 3.5"



6A
 Curved Track to Front
 OW: 3.5"



7A
 Curved Track with T-Cushion
 OW: 3.5"



8A
 Sock to Front
 OW: 5"



9A
 Sock with T-Cushion
 OW: 5"



10A
 Square to Front
 OW: 5"



11A
 Square with T-Cushion
 OW: 5"



12A
 Cap to Front
 OW: 3.5"



13A
 Cap with T-Cushion
 OW: 3.5"



8B
 Straight Border
 OH: 32"



9B
 T-Border
 OH: 32"



10B
 Straight Knife Edge
 OH: 32"



11B
 T-Knife Edge
 OH: 32"




12B
 Lawson Tight
 OH: 31"
 *On 37" OD only



13B
 Lawson Tight with Kidney
 OH: 31"
 *On 40" OD only



12C
 Turned
 OH: 5"



13C
 Platform
 OH: 5"



14C
 Square Taper
 OH: 5"



15C
 Thin Taper
 OH: 5"



16C
 Base To Floor
 OH: 1.5" Hover Foot



17C
 Waterfall Skirt
 with 5" Taper Leg
 *Additional



18C
 Wood Ledge
 OH: 1.5"



19C
 Chrome Ledge
 OH: 1.5"



20C
 Acrylic Ledge
 OH: 1.5"
 *Additional



21C
 Round Taper
 OH: 5"






CHOOSE YOUR STANDARD DEPTH

37"D

40"D

STANDARD TWO ARM CHAIR and SOFA FRAMES * Overall width depends on arm widths: 7" or 10" + Inside Width.



- 37"D DCH/37 Chair DL/37 Loveseat DS/37 Apartment DSS/37 Standard DES/37 Extended DXS/37 Extra Long
- 40"D DCH/40 Chair DL/40 Loveseat DS/40 Apartment DSS/40 Standard DES/40 Extended DXS/40 Extra Long
- OW: 30" or 33" OW: 53" or 56" OW: 67" or 70" OW: 76" or 79" OW: 82" or 85" OW: 99" or 102"
- IW: 23" IW: 46" IW: 60" IW: 69" IW: 75" IW: 92"



STANDARD OTTOMAN FRAMES



- DOT/20 Ottoman DCT/36 Cocktail Ottoman
- OW: 23" OW: 36"
 OD: 20" OD: 36"
 OH: 17" OH: 17"

STANDARD TWO ARM CHAISE FRAMES

* Overall width depends on arm widths: 7" or 10" + Inside Width.






these pieces coordinate with 37" deep frames because of depth and arm length

- DSCH/58 Short Chaise DLCH/75 Long Chaise
- OW: 30" or 33" OW: 30" or 33"
 OD: 58" OD: 75"
 SD: 43" SD: 60"
 IW: 23" IW: 23"

these pieces coordinate with 40" deep frames because of depth and arm length

- DSCH/61 Short Chaise DLCH/78 Long Chaise
- OW: 30" or 33" OW: 30" or 33"
 OD: 61" OD: 78"
 SD: 46" SD: 63"
 IW: 23" IW: 23"

STANDARD ONE ARM CHAISE FRAMES * Overall width depends on arm width: 3.5" or 5" + Inside Width.



these pieces coordinate with 37" deep frames because of depth and arm length

- DSLCH/58 Short Left Arm Chaise DSRCH/58 Short Right Arm Chaise DLLCH/75 Long Left Arm Chaise DLRCH/75 Long Right Arm Chaise
- OW: 26.5" or 28" OW: 26.5" or 28" OW: 26.5" or 28" OW: 26.5" or 28"
- OD: 58" OD: 58" OD: 75" OD: 75"
- SD: 43" SD: 43" SD: 60" SD: 60"
- IW: 23" IW: 23" IW: 23" IW: 23"

these pieces coordinate with 40" deep frames because of depth and arm length

- DSLCH/61 Short Left Arm Chaise DSRCH/61 Short Right Arm Chaise DLLCH/78 Long Left Arm Chaise DLRCH/78 Long Right Arm Chaise
- OW: 26.5" or 28" OW: 26.5" or 28" OW: 26.5" or 28" OW: 26.5" or 28"
- OD: 61" OD: 61" OD: 78" OD: 78"
- SD: 46" SD: 46" SD: 63" SD: 63"
- IW: 23" IW: 23" IW: 23" IW: 23"




STANDARD ONE ARM CHAIR and SOFA FRAMES *Overall width depends on arm width: 3.5" or 5" + Inside Width.




37"D ○ DLC/37 Left Arm Chair




○ DRC/37 Right Arm Chair



○ DLL/37 Left Arm Loveseat



○ DRL/37 Right Arm Loveseat



○ DLS/37 Left Arm Sofa



○ DRS/37 Right Arm Sofa

40"D ○ DLC/40 Left Arm Chair

OW: 26.5" or 28"
IW: 23"

○ DRC/40 Right Arm Chair

OW: 26.5" or 28"
IW: 23"

○ DLL/40 Left Arm Loveseat

OW: 49.5" or 51"
IW: 46"

○ DRL/40 Right Arm Loveseat

OW: 49.5" or 51"
IW: 46"


○ DLS/40 Left Arm Sofa

OW: 72.5" or 74"
IW: 69"


○ DRS/40 Right Arm Sofa

OW: 72.5" or 74"
IW: 69"


STANDARD ONE ARM CORNER SOFA FRAMES *Overall width depends on arm width: 3.5" or 5". Note: Corners include an additional inside back cushion.




37"D ○ DLCL/37 Left Arm Corner Loveseat
OW: 63.5" or 65"
IW: 45"



○ DRCL/37 Right Arm Corner Loveseat
OW: 63.5" or 65"
IW: 45"



○ DLCS/37 Left Arm Corner Sofa
OW: 86.5" or 88"
IW: 68"



○ DRCS/37 Right Arm Corner Sofa
OW: 86.5" or 88"
IW: 68"


40"D ○ DLCL/40 Left Arm Corner Loveseat
OW: 66.5" or 68"
IW: 47"

○ DRCL/40 Right Arm Corner Loveseat
OW: 66.5" or 68"
IW: 47"


○ DLCS/40 Left Arm Corner Sofa
OW: 89.5" or 91"
IW: 70"

○ DRCS/40 Right Arm Corner Sofa
OW: 89.5" or 91"
IW: 70"


STANDARD ARMLESS RETURN SOFA FRAMES *Returns include an additional inside back cushion.




37"D ○ DLRL/37 Armless Left Return Loveseat
OW: 60"
IW: 45"



○ DRRL/37 Armless Right Return Loveseat
OW: 60"
IW: 45"



○ DLRS/37 Armless Left Return Sofa
OW: 83"
IW: 68"



○ DRRS/37 Armless Right Return Sofa
OW: 83"
IW: 68"

40"D ○ DLRL/40 Armless Left Return Loveseat
OW: 63"
IW: 47"

○ DRRL/40 Armless Right Return Loveseat
OW: 63"
IW: 47"

○ DLRS/40 Armless Left Return Sofa
OW: 86"
IW: 70"

○ DRRS/40 Armless Right Return Sofa
OW: 86"
IW: 70"

STANDARD ARMLESS CHAIR and SOFA FRAMES



37"D ○ DAC/37 Armless Chair




○ DAL/37 Armless Loveseat




○ DAS/37 Armless Sofa



○ DCC/37 Corner Chair
OW: 37"
IW: 22"



○ DQTR/37 Quarter Turn
OW: 54" diagonally



○ DWDG/37 Wedge
OW: 52" diagonally

40"D ○ DAC/40 Armless Chair
OW: 23"
IW: 23"

○ DAL/40 Armless Loveseat
OW: 46"
IW: 46"

○ DAS/40 Armless Sofa
OW: 69"
IW: 69"

○ DCC/40 Corner Chair
OW: 40"
IW: 24"

○ DQTR/40 Quarter Turn
OW: 57"

○ DWDG/40 Wedge
OW: 55"

